blackline



Technical User Manual



CONTENTS

Real-time connected safety
Blackline Safety Network
Blackline Live web portal
G7 models
Device comparison
What's in the box
Hardware details
How it works
How it works
SureSafe
Yellow pending alarm
Yellow warning alarm
Red alert
LiveResponse
Charging
Wearing
Power on
Power off
Yellow pending alarm features
Potential Fall detected
Potential no-motion detected
Check-in request
Yellow warning alarm features
Messages
Speaker phone
Network connection interruption
Low battery
Red alert features
Fall detected
No-motion detected
Missed check-in
SOS alart

Bump test
Yellow warning alarm gas features Low warning alarm for gas Under limit Sensor error Calibration Bump test Red alert gas features High alert for gas STEL (short term exposure limit) alert. TWA (time weighted average) alert OL (over limit) alert
Gas Cartridge replacement program
Over-the-air (OTA) firmware updates
Learn more Customer Care
Detailed specifications
Legal notices

OVFRVIFW



What is G7?

G7 is the first true work-everywhere, wearable, personal safety monitor. It keeps you connected — whether it's a gas leak, a health incident or an intruder.

Your G7 can trigger a facility evacuation, accounting for your location on a real-time map. Should you require help, G7 delivers the instant situational awareness needed to manage the fastest possible response to make a difference.

G7 has your back at all times.

How am I connected?

The Blackline Safety Network is the cloud-hosted system used to monitor your safety. It includes 2G/3G cellular networks, satellite networks, our Blackline Live™ web portal application, your monitoring account and your personal safety monitoring device.

Each G7 device requires an active service plan in order to connect to the Blackline Safety Network. Depending on your needs and requirements, there are various service plan options available such as 24/7 safety monitoring by Blackline's Safety Operations Center and two-way voice communication. Contact your organization's safety professional for more information regarding the details of your service plan.

What is Blackline Live?

G7 utilizes the cloud-hosted Blackline Live web portal to monitor and manage all your workers and devices.


With Blackline Live's real-time alerting and live map with employee locations, you can quickly locate and respond to a worker in distress. Real-time alerts show the employees location on the map with the type of alert, enabling your team to efficiently send the help they need.

Blackline Live also allows you to create and customize configuration profiles that determine how a device or a group of devices operates in the field. Similarly, alert profiles are set up to determine what contacts should be notified in the event of an incident and what response protocol monitoring personnel will follow to ensure your team gets the help it needs.

Blackline Live keeps track of alert history, calibrations and bump tests eliminates the need to manually retrieve data logs from the field. All G7 data is communicated in real-time.

G7 is capable of receiving text messages from Blackline Live, with the option of receiving voice communications.

Blackline Live allows you to tailor user access depending on employee roles: employee, supervisor, administrator and monitoring team. This ensures that everyone has access to the right tools to accommodate their role in a comprehensive monitoring program.



What G7 model do I have?

There are two G7 models: G7c and G7x. The main difference between them is how they connect to the Blackline Safety Network.

If you are unsure of which G7 model you have, refer to the logo on the front of your G7.

blackline G7C

G7c works anywhere with 2G/3G cellular coverage in over 200 countries to connect you directly to the Blackline Safety Network. Depending on your service plan, your G7c may have two-way voice capabilities.

blackline G7× Makhteniny Weve carry vous excell

G7x works in conjunction with Blackline's G7 Bridge — a portable satellite base station that keeps you connected in remote locations outside cellular coverage. G7x uses a 900 MHz radio to communicate with G7 Bridge up to 2km away. One G7 Bridge can link up to five G7x devices to the Blackline Safety Network through Iridium satellite or cellular data.

What features does my G7 have?

G7c and G7x are customized with one of three cartridge types. Cartridge selections include Standard, Single-gas and Quad-gas cartridges. The following comparison chart summarizes the features of each cartridge.

ممنايات ماما

م داداد ما دا

	blackline GZ ^C			blackline Gフ×		
						_
	1					
	Standard	Single	Quad	Standard	Single	Quad
Text messaging						
Fall detection				***************************************		
No-motion detection				•		
SOS alert				•	-	
Check-in						
Receive voice calls						
Single gas detection						
Multi gas detection				•	•	
Low warning alarm for gas						
Under limit alarm for gas						
High alert for gas				***************************************		
STEL alert for gas				***************************************		
TWA alert for gas				•••••		
Over limit alert for gas						

Your G7 device comes with the following components:

G7 personal safety monitoring device

Pre-installed cartridge (Standard, Single-gas or Quad-gas cartridge)

Quick start guide

Charging system

Removable charging clip

USB cable

USB power adapter

Certification and support card

If you have a Single-gas or Quad-gas cartridge you will also receive:

Gas detection guide

Single or Quad calibration cap (depending on your cartridge)

Calibration gas tubing

Cartridge (Standard, Single-gas or Quad-gas)

☐ LCD screen

Up button

oκ OK button

也 Power button

Microphone (G7c only)



Top lights
Pending and
warning
Alerts

LiveResponse

SureSafe

◆ Speaker

Down button

① Latch pull

Latch push button

Charging light

Cartridge label

Product label



Metal belt clip

Charging port

INTERACTION

Interacting with G7 is easy with it's high-visibility LCD display and three-button menu system.



OK button

Press OK to enter the main menu on the LCD screen and to confirm a menu selection.



Up and down arrow buttons

Press up or down to navigate the menu. Press and hold both simultaneously to mute a yellow warning alarm or red alert.



Latch pull

Pull down the latch to call for help when assistance is required.



Latch push button

Push the latch in to check in and tell your G7 that you are safe.

NOTIFICATIONS

When G7 has something to tell you it uses color, vibration, sound and on-screen messages.

Are you Connected?

G7 lets you know your connection status.



Blinking green light

A blinking green SureSafe® light indicates your device is connecting to the Blackline Safety Network and your safety is not yet monitored.

Solid green light

A solid green SureSafe light indicates you're connected and being monitored by the Blackline Safety Network.

Sound and vibration

Configurable to sound an alarm if connection is lost after 5 minutes.

10 | G7 TECHNICAL USER MANUAL G7 TECHNICAL USER MANUAL I 11

Are you safe?

G7 is asking you to confirm that you are safe.

Yellow Pending Alarm

Push the red latch button within a set period of time to confirm you are safe. If you don't push the latch button your G7 will communicate a red alert to monitoring personnel.

Sound and Vibration

Beeping alarm sound — an alarm sound and vibration, a pause, then an alarm sound and vibration and another pause, etc.

Yellow Pending Alarms:

Potential fall detected Potential no-motion detected Check-in request

G7 has a message for you

Read your G7 screen.

Yellow Warning Alarm

Press and hold the up and down buttons at the same time to let your G7 know you have read the message. This will disable the audible and visual alarm.

Sound and Vibration

Urgent alarm sound — an alarm sound and vibration, a pause, another alarm sound and vibration, another pause, etc. (Faster than yellow pending alarm sound).

Yellow Warning Alarms:

New message

Voice call

Network connection interruption

Low battery

Low warning alarm for gas

Sensor error

Under limit

Calibration

Bump test

12 | G7TECHNICAL USER MANUAL G7TECHNICAL USER MANUAL | 13

We're here to help

If you need assistance or have not responded to a yellow pending alarm.

Red Alert

Red alerts are immediately communicated to monitoring personnel. Read the information on your screen. Press and hold the up and down buttons simultaneously to mute. Muting will only silence the sound and vibration and does not cancel the alert to monitoring personnel.

Sound and vibration

Critical alarm sound — an urgent sound and a constant vibration without any pauses.

Red Alerts:

Fall detected

No-motion detected

Missed check-in

SOS alert

High alert for gas


STEL alert for gas

TWA alert for gas

Over limit alert for gas

We've got your back

Monitoring personnel have acknowledged your red alert.



Lets you know that remote monitoring personnel are responding by following your team's emergency protocol. Once monitoring personnel have resolved the red alert, the blue LiveResponse™ light will shut off.

Sound and Vibration

Depending on your response protocol, a G7c with voice enabled service plan will automatically connect your speaker phone to monitoring personnel.

OPERATING

How do I charge my G7?

Insert the micro USB plug into the removable charging clip, then slide the clip onto the charging port at the bottom of your G7. A solid red light at the bottom of the device confirms your G7 is charging. The LCD screen will let you know when it is fully charged.

Blackline recommends that you fully charge your device after every shift.

Charging will automatically turn your G7 off to ensure it will not trigger alerts while in the charging process.



Where do I wear my device?

G7 monitors you best when clipped to your belt or chest pocket.

How do I turn on my G7c?

Press and hold the power button, and wait for the blinking green SureSafe light to turn solid. Once connected, the green light will stay on and your safety is being monitored.

How do I turn on my G7x?

Press and hold the power button on your G7 Bridge to turn it on first, and wait for the blinking green SureSafe light to turn solid, It takes approximately two minutes for G7 Bridge to connect to the Blackline Safety Network. Once connected, the green light will stay on.

Press and hold the power button on your G7x. Wait for the blinking green SureSafe light to turn solid. Once connected, the green light will stay on and your safety is being monitored.

For best results, ensure your G7 Bridge is turned on before your G7x. If you are having difficulties connecting your G7x to G7 Bridge, please refer to your G7 Bridge manual.

How do I turn off my G7c?

Press and hold the power button. The device will go into shutdown sequence, once all the lights and vibrations have stopped, you have been logged off from the Blackline Safety Network and your safety is no longer being monitored.

How do I turn off my G7x?

Press and hold the power button of your G7x. The device will go into shutdown sequence, sending your log off status to G7 Bridge.

When suitably powered, G7 Bridge can remain on at all times. When G7 Bridge is off, all connected devices will no longer be monitored. Before powering down, ensure there are no other personal safety monitoring devices connected. Once confirmed, press and hold the power button on the G7 Bridge. The device will go into shutdown sequence. Your safety is no longer being monitored.

For more information, please refer to the G7 Bridge technical user manual.

SAFETY MONITORING FEATURES

Your G7 is equipped with many features to monitor your safety. They are categorized into the type of notifications they trigger — yellow pending alarms, yellow warning alarms, and red alerts. All are customizable in Blackline Live to best fit your needs. Speak to your safety supervisor to learn about how your G7 features are configured.

POTENTIAL FALL DETECTED

What is a potential fall detected?

Your device is constantly monitoring you for falls. If a potential fall is detected, G7 will initiate a yellow pending alarm. The fall detection sensitivity is configurable.

POTENTIAL NO-MOTION DETECTED

What is a potential no-motion detected?

Your device is constantly monitoring your motion. It will automatically detect if you do not move within a pre-set duration, and will initiate a yellow pending alarm. The no-motion period and sensitivity are configurable.

CHECK-IN REQUEST

What is a check-in?

If enabled, you can configure your device to request periodic check-ins throughout your shift. The check-in countdown is displayed at the top right of the LCD screen. At the end of the timer, your G7 will initiate a yellow pending alarm to confirm you are safe. The check-in timer and pending alarm time are configurable.

Your device can be configured to check-in early, before the yellow pending alarm sounds. If enabled, you can push and hold the red latch button for the duration of three vibrations to reset your check-in timer without waiting for the audible alarm. An early check-in cannot be configured if Silent SOS alert is enabled.

What do I do in the case of a yellow pending alarm?



If you are safe, push the red latch button. If you do not push the latch within the configured amount of time, your yellow pending alarm will communicate a red alert to monitoring personnel.

While driving at speeds above 35 km/hr (22 mph), your G7 will not go into alarm for a check-in, potential fall detected or potential no-motion detected.

MESSAGES

How do I receive a message?

Your device can receive messages from monitoring personnel. When there is an incoming message, G7 will inform you with a yellow warning alarm.

How do I send a message?

You can choose from a list of 10 pre-programmed messages to send to monitoring personnel. The messages can be pre-programmed on Blackline Live. Press the OK button to enter the main menu, the up or down arrow buttons to navigate the menu, highlight your selection, and the OK button to send.

How do I send a custom message?

At the bottom of the pre-programmed message list is an option to send a 16-character custom message to monitoring personnel. Press the up or down arrow buttons to scroll through the alphabet and numbers, press the OK button to move to the next character, press the OK button again to send.

In the confirmation screen of your custom message, you have the ability to edit the current message by pressing the up arrow button, send the message by pressing the OK button or cancel the message by pressing the down arrow button.

SPEAKER PHONE

How do I use two-way voice calling?

If you have a G7c with a voice-enabled service plan, your speakerphone will automatically answer a call from monitoring personnel. G7 will inform you of an incoming call with a yellow warning alarm. The blue LiveResponse light will blink and you will hear a beep signifying the two-way voice call has been connected. In a noisy environment, it may be necessary to remove and hold the device near your ear, as you would a two-way radio.

Pull the red latch to have monitoring personnel initiate a voice call.

NETWORK CONNECTION INTERRUPTION

How do I know if the connection to my device is lost?

If your device loses connection with the Blackline Safety Network, it will inform you with a yellow warning alarm after 5 minutes. This amount of time is configurable.

LOW BATTERY

How do I know if my device battery is low?

If your battery level goes below 20%, it will inform you with a yellow warning alarm. This percentage level is configurable.

What do I do in the case of a yellow warning alarm?



Read your G7 screen. Press and hold the up and down arrow buttons at the same time to let your G7 know you have read the message.

Yellow warning alarms are between you and your G7, and will not notify monitoring personnel.

MISSED CHECK-IN

What is a missed check-in?

If enabled and you are unable to check-in during the yellow pending alarm time, your device will communicate a red alert to monitoring personnel.

SOS ALERT

What is an SOS Alert?

If you require assistance, you can manually send an SOS alert to monitoring personnel requesting immediate help to your location by pulling the red latch.

Your device can be configured to send a Silent SOS alert to monitoring personnel without light, sound and vibration.

FALL DETECTED

What is fall detected?

If your device detects a fall and you have not responded to the yellow pending alarm, G7 will communicate a red alert to monitoring personnel. The fall detection sensitivity is configurable.

NO-MOTION DETECTED

What is no-motion detected?

If you are not moving and you have not responded to the yellow pending alarm, G7 will communicate a red alert to monitoring personnel. The no-motion period and sensitivity are configurable.



Red alerts are immediately communicated to monitoring personnel. Read the information on your G7 screen. Press and hold the up and down arrow buttons at the same time to mute the sound and vibration. This does not cancel the red alert sent to monitoring personnel.

GAS DETECTION

Included with your G7 Single-gas or Quad-gas cartridge is a calibration cap and tubing for bump tests and calibrations. Alternatively, bump tests and calibrations can be completed using a G7 Dock. Only perform bump test and calibrations in a safe environment. For more information and instructions, refer to the G7 Dock technical user manual.

What is a bump test?

It is safe practice to regularly test alarm indicators (lights, sound and vibration) by applying enough gas to confirm the sensors will trigger an alarm when gas is detected. G7 communicates bump test data automatically to the Blackline Safety Network, and will remind you when a bump test is overdue. The bump test schedule is configurable.

To meet CSA LEL performance standard, you are required to bump test before each day's use. Blackline recommends you do not exceed 30 days without a bump test.

How do I bump test?

Attach tubing to the calibration cap

Ensure the other end of the tubing is attached to a 0.5 L/min regulator on the gas tank On your G7, press the OK button to enter the main menu

Press the arrow buttons to navigate to Bump Test

Press the OK button to select Bump Test

Press the OK button to continue

G7 preforms an automatic audio and visual assessment to test vibration and lights You can individually choose which sensors to test, by default G7 will test all sensors

Attach the calibration cap to your device

G7 will begin to count down from 60, apply the gas within this time window

Turn gas off when prompted on your G7 screen

Press the OK button to complete bump test

G7 will let you know if the bump test has passed or failed, and when your next bump test is due

Remove the calibration cap and let your G7 sit until the readings stabilize and your G7 is regulated





What is calibration?

Gas sensors periodically need to be calibrated by applying a known concentration of gas for a set amount of time. This procedure ensures the gas sensor can accurately detect gas levels throughout its operating life. The calibration schedule depends on your company's safety policy. Blackline recommends not exceeding 180 days without a calibration.

How do I calibrate?

Attach tubing to the calibration cap

Ensure the other end of the tubing is attached to a 0.5 L/min regulator on the gas tank

On your G7, press the OK button to enter the main menu

Press the arrow buttons to navigate to Calibration Press the OK button to select calibration

Press the OK button to continue

G7 preforms an automatic audio and visual assessment to test vibration and lights

You can individually choose which sensors to test, by default G7 will test all sensors

Attach the calibration cap to your device

G7 will begin to count down from 60, start applying gas within this time window

and continue to apply gas for 2 minutes

Turn gas off when prompted on your G7 screen

Press the OK button to complete calibration

G7 will let you know if the calibration has passed or failed, and when your next

calibration is due

Remove the calibration cap and let your G7 sit until the readings stabilize and your

G7 is calibrated

If you see a calibration fail message on your LCD screen, try the calibration again. If the error persists, please contact our Customer Care team.

What is zeroing?

If G7 is not reading zero and you know you are in an atmosphere with no gas, your gas sensor readings may have shifted. If this happens, it is best to calibrate your sensors. If you are unable to preform a calibration, you can zero your sensors to reset the baseline.

G7 can be configured to automatically zero on start-up when you turn on your device in Blackline Live.

The baseline reading for oxygen is 20.9.

How do I zero sensors?

On your G7, press the OK button to open the main menu

Press the arrow buttons to navigate to Zero Sensors

Press the OK button to select zeroing

G7 will do an automatic audio and visual assessment to test vibration and lights

Press the OK button to start zeroing, do not apply any gas

The LCD screen will let you know once zero is complete

If you see a zero incomplete message on your LCD screen you may be in an environment with gas levels, or your cartridge may need replacement.

GAS DETECTION FEATURES

Once you have completed the bump test and calibration, your G7 is ready to monitor and notify you of gas exposure. Gas detection alarms will notify you with either a yellow warning alarm or a red alert depending on the gas level measured. All settings are customizable in Blackline Live. Speak to your safety supervisor to learn about how your G7 gas features are configured.

LOW WARNING ALARM FOR GAS

When does G7 trigger a low yellow warning alarm for gas?

When gas levels reach the low concentration configured by your safety supervisor, G7 will inform you with a yellow warning alarm every two minutes until gas levels are reduced.

A G7 with $\rm O_2$ sensors will trigger low warning alarms in oxygen-deficient and oxygen-enriched atmospheres. An oxygen-deficient atmosphere poses a risk of insufficient oxygen for breathing. An oxygen-enriched atmosphere presents an increased risk of explosion.

UNDER LIMIT

When does G7 trigger an under limit yellow warning alarm?

If a gas sensor's baseline shifts, it's reading will shift accordingly and become unreliable. When this happens, the presence of gas can still be measured, but cannot be converted into an accurate reading. G7 will inform you of such an event with a yellow warning alarm. A calibration will be required to ensure the sensors are accurately detecting gas levels. If you are unable to perform a calibration and are in a clean atmosphere, you can zero your sensors to reset the baseline.

SENSOR FRROR

When does G7 trigger a sensor error yellow warning alarm?

If a gas sensor stops working for any reason, G7 will inform you with a yellow warning alarm. An X on your LCD screen will indicate which sensor or sensors are generating the error message. Power off and restart your G7. If the sensor error warning persists, perform a calibration. If this does not correct the problem, you will need to replace your cartridge.

CALIBRATION

When does G7 trigger a calibration yellow warning alarm?

When gas sensors are due for a calibration, G7 will inform you with a yellow warning alarm.

BUMP TEST

When does G7 trigger a bump test yellow warning alarm?

When gas sensors are due for a bump test, G7 will inform you with a yellow warning alarm.

What do I do in the case of a yellow warning alarm?



Read your G7 screen. Press and hold the up and down arrow buttons at the same time to let your G7 know you have read the message.

Yellow warning alarms are between you and your G7, and will not notify monitoring personnel.

HIGH ALERT FOR GAS

When does G7 trigger a high alert for gas?

If a gas sensor detects gas levels above the maximum gas concentration configured by your safety supervisor, G7 will communicate a red alert to monitoring personnel.

A G7 with $\rm O_2$ sensors will trigger red alerts in both oxygen-deficient and oxygenenriched situations.

STEL (SHORT TERM EXPOSURE LIMIT) ALERT

When does G7 trigger a STEL alert?

If a gas sensor detects you have reached the short-term exposure limit configured by your safety supervisor, your G7 will communicate a red alert to monitoring personnel. This limit is the gas concentration that you can be continuously exposed to for a 15-minute time frame without suffering adverse health effects.

TWA (TIME WEIGHTED AVERAGE) ALERT

When does G7 trigger a TWA alert?

If a toxic sensor detects you have exceeded the average allowable amount of gas during an eight-hour period, G7 will communicate a red alert to monitoring personnel.

The two TWA measuring methods available for use on your G7 are:
OSHA (United States Department of Labor Occupational Safety and Health Administration)
or ACGIH (American Conference of Governmental Industrial Hygienists).

OSHA is defined as a rolling average of gas exposure accumulated over an eight-hour period of operation. If the worker is in the field longer, the most recent eight-hour cumulative value is used.

ACGIH is defined as the total accumulated average, from four to 16 hours as configured by your safety supervisor.

OL (OVER LIMIT) ALERT

When does G7 trigger an OL alert?

If a gas sensor detects an excessive amount of gas and can no longer give you an accurate reading, G7 will communicate a red alert to monitoring personnel.



Evacuate the area and follow your emergency safety protocol.

Red alerts are immediately communicated to monitoring personnel. Read the information on your G7 screen. Press and hold the up and down arrow buttons at the same time to mute the sound and vibration. This does not cancel the remote alert sent to monitoring personnel. The sound and vibration will return after one minute. This will continue until gas levels or averages have reduced or returned to acceptable concentrations.

CARTRIDGES

What do I do when I need a new gas cartridge?

If you have an uninterrupted service plan for your G7 gas cartridge, Blackline will replace expired cartridges for you free of charge. To inquire about or request new cartridges, please contact our Customer Care team or your distributor.

How do I change my G7 cartridge?

Power off G7

Using a Torx T8 screwdriver, remove the screws on each side of the device Pull up on the cartridge

Slide a new cartridge onto G7, ensuring the cartridge clicks into place Replace screws into each side of the device



Sensor contaminants

Gas sensors are susceptible to contamination by a variety of common chemicals, reducing or eliminating their sensitivity. Care should be taken when using silicones, cleaners, solvents and lubricants in close proximity to sensors as exposure may cause permanent damage to the sensor. If a device is exposed to a new chemical or compound, it is best practice to bump test and calibrate units to ensure proper sensor function is maintained.

CAUTION

For safety reasons this equipment must be operated and serviced by qualified personnel only. Read and understand instruction manual completely before operating or servicing.

To meet the CSA LEL performance standard, the following safety precautions should be considered:

Before each day's usage sensitivity must be tested on a known concentration of methane equivalent to 25-50% of full scale concentration. Accuracy must be within 0 and 20% of actual. Accuracy may be correct by calibration.

Any rapid up-scale reading followed by declining or erratic reading may indicate a gas concentration beyond upper scale limit which may be hazardous.

High off-scale readings may indicate an explosive concentration.

This area must be free of flammable gases during calibration.

32 | G7 TECHNICAL USER MANUAL G7 TECHNICAL USER MANUAL G7 TECHNICAL USER MANUAL 33

FIRMWARE UPDATES

SUPPORT

How does G7 get updated?

To offer new features, Blackline Safety periodically releases over-the-air (OTA) firmware updates. Your G7 device will automatically download and install the new firmware.

Blackline Safety will contact you directly for specific information about new updates. If you have any questions, please contact our Customer Care team.

OTA firmware updates are only available for G7 Bridge when it is brought into cellular range. If G7 Bridge cannot be removed from satellite only reception, contact Customer Care to receive a firmware update kit.

Visit support.BlacklineSafety.com to find support and training materials for G7.

For technical support, please contact our Customer Care team.

North America (24 hours)

Toll Free: 1-877-869-7212 | support@blacklinesafety.com

United Kingdom (8am-5pm GMT)

+44 1787 222684 | eusupport@blacklinesafety.com

International (24 hours)

+1-403-451-0327 | support@blacklinesafety.com

34 | G7TECHNICAL USER MANUAL G7TECHNICAL USER MANUAL | 35

SPECIFICATIONS

Standard G7 Safety Alert Features

All safety alerts are transmitted in real-time to the Blackline Safety Network

Fall detection and No-motion detection: Tri-axis accelerometer, tri-axis gyro, software processing, configurable sensitivity, configurable time window (1-30 mins, or off) for no-motion detection SOS latch: Pull latch to trigger remote alert Silent emergency: Press and hold latch to trigger remote alert Low-battery: configurable threshold

Additional Gas Cartridge Features

off), automatic check-in when driving

Check-in: Configurable timer (15 – 180 min, or

All gas alerts are transmitted in real-time to the Blackline Safety Network

Over limit Under limit Time-weighted average (TWA) Short-term exposure limit (STEL) High gas alert Low gas alert Bump test and calibration notification Bump test and calibration failure alert

Size & Weight

G7 with Standard Cartridge

Size: 64 mm x 124 mm x 27 mm (2.52" x 4.88" x 1.06") Weight: 162 g (5.7 oz)

G7 with Single-gas Cartridge

Size: 64 mm x 128 mm x 27 mm (2.52" x 5.04" x 1.06") Weight: 167 g (5.9 oz)

G7 with Quad-gas Cartridge

Size: 66 mm x 150 mm x 27 mm (2.52" x 5.91" x 1.06")

Weight: 192 g (6.8 oz)

Gas Sensor Options

H₂S, LEL, CO, O₂, CO₂, NH₃

H₂S (Hydrogen Sulfide) Sensor type: Electrochemical Lowest detection limit: 0.5 ppm Upper detection limit: 50 ppm Resolution: 0.1 ppm

LEL Combustible

Sensor type: MEMS pellistor or NDIR Lowest detection limit: 4% LEL Upper detection limit: 100% LEL Resolution: 1% LEL

CO (Carbon Monoxide)

Sensor type: Electrochemical Lowest detection limit: 1 ppm Upper detection limit: 500 ppm Resolution: 1 ppm

O₂ (Oxygen)

Sensor type: Pumped electrochemical Lowest detection limit: 0.1% vol Upper detection limit: 25.0% vol Resolution: 0.1% vol

CO₂ (Carbon Dioxide)

Sensor type: Infrared

Lowest detection limit: 50 ppm **Upper detection limit:** 50000 ppm

Resolution: 50 ppm

NH₃ (Ammonia)

Sensor type: Electrochemical Lowest detection limit: 0.5 ppm Upper detection limit: 100.0 ppm

Resolution: 0.1 ppm

For a full range of supported gas sensors contact Blackline Safety.

User Interface

168 by 144 pixel graphical, high contrast, liquid crystal display with front lighting, menu system driven by three-button keypad, power button (on/ off), check-in button (check-in/silent SOS), SOS latch (send emergency alert)

User Notification

Green SureSafe® light: Blinking (powered), continuous (connected)

Yellow top and front lights: Personal pending alarm and personal warning alarm

Red top and front lights: Alert communicated Blue LiveResponse[™] top and front lights: Monitoring team confirmation that alert has been acknowledged Personal alarm Indicators: speaker, LEDs and vibration motor

Speaker sound pressure level: ~90 dB @ 10 cm (~90 dB @3.94")

Voice calling: Speakerphone and phone modes (G7c model only)

G7c Wireless Radio

Wireless coverage: ~200 countries North America: 2G/3G radio, GSM 850 MHz, PCS 1900 MHz, 3G UMTS bands 2, 5 and 6 International: 2G/3G radio, E-GSM 900 MHz, DSC 1800 MHz, 3G UMTS bands 1 and 8 Antenna: Internal regionally optimized

G7x Wireless Radio

Works with G7 Bridge satellite base station Radio: 902.0 - 928.0 MHz, 1 Watt

Antenna: Internal

Radio link range: 2 km (1.25 mi) real-world

Wireless Updates

Device configuration changes: Yes Device firmware upgrade over-the-air (FOTA): Yes

Location Technology

GPS Radio: 48-channel high sensitivity

Assisted-GPS: Yes (G7c model only) GPS Accuracy: ~5 m (16 ft) Outdoors

Indoor location technology: Blackline Safety location beacons Location update frequency: G7c 5 min, G7x 15 min defaults

Power & Battery

Rechargeable Li-ion battery: 1100 mAh Li-ion Battery Life: 18 hours at 20°C (68°F) under normal usage

Charge time: 4 hours

Environmental

Storage temperature: -30°C to 60°C (-22°F to 167°F) Operating temperature: -20°C to 55°C (-4°F to 131°F) Charging temperature: 0°C to 45°C (32°F to 113°F) **Ingress Protection:** Designed to meet IP67

Approvals*

G7c: SAR, RoHS, CE, RCM FCC ID: XPY1CGM5NNN | IC ID: 8595A-1CGM5NNN Intrinsically safe: Class I Division 1 Groups A, B, C, DT4; Class I Zone O AEx ia IICT4 Ga; Ex ia IICT4 Ga

G7x: SAR, RoHS, RCM

FCC ID: W77G7X | IC ID: 8255A-G7X Intrinsically safe: Class I Division 1 Groups A, B, C, DT4; Class I Zone 0 AEx ia IICT4 Ga: Ex ia IICT4 Ga: IECEx Ex ib IICT4 Gb

Warranty

G7: two years limited warranty

Cartridges: lifetime warranty and sensor replacements

with service plan

Blackline Complete: three year operating lease

Blackline Live Web Application

Cloud-hosted safety monitoring web application is highly customizable for every customer requirement. Includes live map, employee address book, user roles, alert management, device configurations, alert setups and reporting.

* Check with Blackline for approval status. All specifications subject to change.

LEGAL NOTICES AND CERTIFICATIONS

Information in this document is subject to change without notice. This document is provided "as is" and Blackline Safety Corp. ("Blackline") and its affiliated companies and partners assume no responsibility for any typographical, technical or other inaccuracies in this document. Blackline reserves the right to periodically change information that is contained in this document. However, Blackline makes no commitment to provide any such changes, updates, enhancements or other additions to this document to you in a timely manner or at all.

Copyright © 2016 Blackline Safety Corp. All rights reserved.

Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded, or stored in any storage medium, for any purpose without the express prior written consent of Blackline Safety Corp ("Blackline"). Blackline hereby grants permission to download a single copy of this manual onto some form of electronic storage medium to be viewed and to print one copy of this manual or any revision hereto, provided that such electronic or printed copy of this manual must contain the complete text of this copyright notice. Further, any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited.

The Blackline, Alert. Locate. Respond. families of related marks, images and symbols, including Blackline, G7, G7c, G7x, LiveResponse, Loner, Loner IS, Loner IS+, Loner M6, Loner M6i, Loner Mobile, Loner 900, and SureSafe are the exclusive properties and trademarks of Blackline Safety Corp. All other brands, product names, company names, trademarks and service marks are the properties of their respective owners.

Warranty

Your G7 device is warranted against defects in materials and workmanship for up to two years from date of purchase. For further details regarding your Blackline warranty, please refer to your terms and conditions of service.

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: the grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for further assistance.

Industry Canada Compliance

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Notification d'Industrie Canada

Ce dispositif est conforme au(x) format(s) RSS libre(s) d'Industrie Canada. Son fonctionnement est assujetti aux deux conditions suivantes: (1) Cet appareil ne peut causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant provoquer un mauvais fonctionnement du dispositif.

Warning

Do not operate Blackline Safety products where you are not able to safely operate your mobile/cellular phone.

Electrical equipment may be hazardous if misused. Operation of this product, or similar products, must always be supervised by an adult. Do not allow children access to the interior of any electrical product and do not permit them to handle any cables.

Do not operate or store Blackline products outside their specified operating or storage temperatures. Consult the specifications section for more information

Blackline products may contain an internal lithium-ion battery pack. Seek advice from your local electronics recycling authority regarding the disposal of your device. Do not dispose Blackline products in your household trash.

Intrinsically Safe

This device is certified Intrinsically Safe for use in Class I Division 1 Groups A,B,C,DT4; Ex da ia IICT4 Ga; Class I Zone 0 AEx da ia Group IICT4 Ga hazardous (classified) locations. G7x is certified as Ex ib IIC T4 Gb under IECEx.

Sécurité intrinsèque

Cet appareil est certifié à sécurité intrinsèque pour l'usage en classe I division 1 groupe A,B,C,D T4; Ex da ia IIC T4 Ga; classe I zone 0 AEx da ia groupe IIC T4 Ga dans les lieux classés comme dangereux.

CSA: 70098755 UL 60079

Class I Division 1 Groups A,B,C,D;T4 Class I Zone O AEx da ia IICT4 Ga

CAN/CSA C22.2 No. 60079 Ex da ia IICT4 Ga

IECEX/ATEX: IECEX CSA 17.0005: Sira 17ATEX2083X IEC 60079; EN 60079 G7c: Ex da ia IIC T4 Ga G7x: Ex ib IIC T4 Gb







Base unit P/N "G7*-#" (* = c or x; # = NA, EU or AZ) Gas cartridge: Standard P/N "Z" | Single-gas P/N "S-#" | Multi-gas P/N "O-####" (# = Electro chemical sensor identifier or "X" indicating no sensor)

Caution: For safety reasons this equipment must be operated and serviced by qualified personnel only. High off-scale readings may indicate explosive concentration.

The equipment shall only be charged L'équipement ne doit être chargé que when in the non-hazardous area for use with the unit (for example part number SAW06D-050-1000xx. manufactured by Shenzhen Shi Ying Yuan Electronics Co., Ltd.), approved as SELV or Class 2 equipment against IEC 60950, IEC 61010-1 or an equivalent IEC standard. The maximum voltage and current from the charger shall not exceed 5.625Vdc and 2A respectively.

Attention: Pour des raisons de sécurité, cet équipment doit être utilisé, entretenu et réparé uniquement par un personnel qualifié. Des lectures supérieures à l'échellepeuvent indiquer des concentration explosives.

dans la zone non dangereuse à l'aide using a charger specifically supplied d'un chargeur spécifiquement fourni pour l'utilisation avec l'appareil (par exemple, la référence SAW06D-050-1000xx, fabriquée par Shenzhen Shi Ying Yuan Electronics Co., Ltd.) SELV ou Classe 2 selon IEC 60950, IEC 61010-1 ou une norme IEC équivalente. La tension et le courant maximum du chargeur ne doivent pas dépasser respectivement 5.625Vdc et 2A.

Standards:

UL 60079-0: 2013 UL 60079-11: 2013 CAN/CSA C22.2 No. 60079-0: 2015 CAN/CSA C22.2 No. 60079-11: 2014

Consult with your organization's Sîl vous plaît consulter professionnel de la safety professional for further procedures, facilities, or locations les procédures, les installations, ou within facilities that may be related to intrinsic safety.

EN 60079-0: 2012 EN 60079-11: 2012 IEC 60079-0: 2011 IEC 60079-11: 2011

sécurité de votre organisation pour de plus information regarding the topic amples informations concernant le sujet of intrinsic safety and any policies, de la sécurité intrinsèque et les politiques, emplacements au sein des établissements qui peuvent être liés à la sécurité intrinsèque.

Blackline Safety | Suite 101, 1215 - 13 Street SE | Calgary, AB T2G 3J4 | Canada

0187/R2/2018-02-09

38 | G7 TECHNICAL USER MANUAL G7 TECHNICAL USER MANUAL | 39

blackline

www.BlacklineSafety.com